

AEM00900 Evaluation Board User Guide

Description

The AEM00900 evaluation kit (EVK) is a printed circuit board (PCB) featuring all the required components to operate the AEM00900 integrated circuit (IC) in QFN28 package.


The AEM00900 evaluation board allows users to test the e-peas IC and analyze its performances in a laboratory-like setting or in product mock-ups.

It allows easy connections to an energy harvester (e.g. a single element PV cell) and a storage element. It also provides all the configuration access to set the device in any of the modes described in the datasheet. The control and status signals are available on standard pin headers or through an I²C bus communication, allowing users to override preconfigured board settings through host MCU and evaluate the IC performances.

The AEM00900 EVK is a plug and play, intuitive and efficient tool to optimize the AEM00900 configuration, allowing users to design a highly efficient subsystem for the desired target application. Component replacement and operating mode switching is convenient and easy.

More detailed information about AEM00900 features can be found in the datasheet.

Appearance



Features

Two-way screw terminals

- Source of energy (DC).
- Energy storage element (battery).
- Thermistor used for thermal monitoring.

2-pin "Shrouded Header"

- Alternative connector for the storage element.

3-pin headers

- Constant source voltage (SRC_LVL_CFG) configuration.
- Energy storage element threshold configuration.
- Mode configuration.
- Thermal monitoring configuration.

6-pin header

- I²C communication pins.

Applications

| | |
|----------------------|-------------------------|
| Wearable Electronics | Keyboards |
| Remote Control Units | Electronic Shelf Labels |
| Smart Buildings | Indoor Sensors |

Evaluation Kit Information

| Part Number | Dimensions |
|----------------------|---------------|
| 2AAEM00900C001 REV:2 | 76 mm x 50 mm |

Device Information

| Part Number | Package | Body size |
|-----------------|------------|-----------|
| 10AEM00900C0000 | QFN 28-pin | 4x4mm |

1. Connections Diagram




Figure 1: Connection diagram

1.1. Signals Description

| NAME | FUNCTION | CONNECTION | |
|-------------------------------|--|--|--|
| | | If used | If not used |
| Power signals | | | |
| SRC | Connection to the harvested energy source. | Connect the source element. | Can be left floating. |
| STO | Connection to the energy storage element. | Cannot be left floating, voltage must always be above 2.8 V. | |
| I²C_VDD | Connection to I ² C voltage supply. | Connect to I ² C supply. | Connect to GND. |
| VINT | AEM Internal voltage supply. | | |
| BUFSRC | AEM connection to a capacitor buffering the boost converter input (no connector on EVK). | | |
| Configuration signals | | | |
| SRC_LVL_CFG[5:0] | Used for the configuration of the source voltage level. | Connect jumpers. | Read as high if left floating. |
| STO_CFG[2:0] | Configuration of the threshold voltages for the energy storage element. | Connect jumpers. | Read as high if left floating. |
| TH_MON | Configuration of the thermal monitoring. | Connect a thermistor. | Connect to VINT . |
| Control signals | | | |
| DIS_STO_CH | Disabling pin for the storage charging. | Connect jumper (see Section 2.5.1). | Read as low if left floating. |
| KEEP_ALIVE | Enabling pin to supply internal circuitry from the storage element if no power on SRC . | Connect jumper (see Section 2.5.1). | Read as low if left floating. |
| I²C signals | | | |
| SDA | Bidirectional data line. | Connect to host I ² C bus. | Connect I²C_VDD to GND (SDA and SCL will be pulled down by R₁ and R₂). |
| SCL | Unidirectional serial clock. | | |
| IRQ | Interrupt request. | Connect to host GPIO. | Leave floating. |

Table 1: Pin description

2. General Considerations

2.1. Safety Information

Always connect the elements in the following order:

1. Reset the board: push the “RESET” (SW2) switch during 5 seconds minimum.
2. Completely configure the PCB (jumpers/resistors):
 - Battery configuration.
 - Mode configuration.
 - Thermal monitoring configuration.
3. Connect I2C_VDD:
 - To GND if I²C is not used (SDA and SCL will also be connected to GND through their pull up resistors).
 - To a power supply if I²C is used (1.5 V to 2.2 V).
4. Connect the storage elements on STO with a voltage higher than 2.8 V.
5. Connect the source to the SRC connector (open circuit voltage lower than 2.0 V).

2.2. Basic Configurations

| Configuration pins | | | | | | Voltage Level |
|--------------------|---|---|---|---|---|---------------|
| SRC_LVL_CFG[5:0] | | | | | | $V_{SRC,REG}$ |
| L | L | L | H | H | L | 0.12 V |
| L | L | L | H | H | H | 0.13 V |
| L | L | H | L | L | L | 0.15 V |
| L | L | H | L | L | H | 0.16 V |
| L | L | H | L | H | L | 0.18 V |
| L | L | H | L | H | H | 0.19 V |
| L | L | H | H | L | L | 0.21 V |
| L | L | H | H | L | H | 0.22 V |
| L | L | H | H | H | L | 0.24 V |
| L | L | H | H | H | H | 0.25 V |
| L | H | L | L | L | L | 0.27 V |
| L | H | L | L | L | H | 0.28 V |
| L | H | L | L | H | L | 0.30 V |
| L | H | L | L | H | H | 0.33 V |
| L | H | L | H | L | L | 0.36 V |
| L | H | L | H | L | H | 0.39 V |
| L | H | L | H | H | L | 0.42 V |
| L | H | L | H | H | H | 0.45 V |
| L | H | H | L | L | L | 0.48 V |
| L | H | H | L | L | H | 0.51 V |
| L | H | H | L | H | L | 0.54 V |
| L | H | H | L | H | H | 0.57 V |
| L | H | H | H | L | L | 0.60 V |
| L | H | H | H | L | H | 0.63 V |
| L | H | H | H | H | L | 0.66 V |
| L | H | H | H | H | H | 0.69 V |

| Configuration pins | | | | | | Voltage Level |
|--------------------|---|---|---|---|---|---------------|
| SRC_LVL_CFG[5:0] | | | | | | $V_{SRC,REG}$ |
| H | L | L | L | L | L | 0.72 V |
| H | L | L | L | L | H | 0.75 V |
| H | L | L | L | H | L | 0.78 V |
| H | L | L | L | H | H | 0.81 V |
| H | L | L | H | L | L | 0.84 V |
| H | L | L | H | L | H | 0.87 V |
| H | L | L | H | H | L | 0.90 V |
| H | L | L | H | H | H | 0.93 V |
| H | L | H | L | L | L | 0.96 V |
| H | L | H | L | L | H | 0.99 V |
| H | L | H | L | H | L | 1.02 V |
| H | L | H | L | H | H | 1.05 V |
| H | L | H | H | L | L | 1.08 V |
| H | L | H | H | L | H | 1.11 V |
| H | L | H | H | H | L | 1.14 V |
| H | L | H | H | H | H | 1.17 V |
| H | H | L | L | L | L | 1.20 V |
| H | H | L | L | L | H | 1.23 V |
| H | H | L | L | H | L | 1.26 V |
| H | H | L | L | H | H | 1.29 V |
| H | H | L | H | L | L | 1.32 V |
| H | H | L | H | L | H | 1.35 V |
| H | H | L | H | H | L | 1.38 V |
| H | H | L | H | H | H | 1.41 V |
| H | H | H | L | L | L | 1.44 V |
| H | H | H | L | L | H | 1.47 V |

Table 2: Configuration of SRC_LVL_CFG[5:0]

| Configuration | Availability Through Pins | | Storage Element Threshold Voltage | |
|---------------|----------------------------|--------------------|-----------------------------------|-------------|
| STO_CFG[2:0] | I ² C Interface | Configuration pins | V_{OVCH} | V_{OVDIS} |
| LLL | yes | yes | 4.50 V | 3.30 V |
| LLH | yes | yes | 4.00 V | 2.80 V |
| LHL | yes | yes | 3.63 V | 2.80 V |

Table 3: Usage of STO_CFG[2:0]



| Configuration | Availability Through Pins | | Storage Element Threshold Voltage | |
|---------------|---------------------------|-----|-----------------------------------|--------|
| LHH | yes | yes | 3.90 V | 2.80 V |
| HLL | yes | yes | 3.90 V | 3.50 V |
| HLH | yes | yes | 3.90 V | 3.01 V |
| HHL | yes | yes | 4.35 V | 3.01 V |
| HHH | yes | yes | 4.12 V | 3.01 V |

Table 3: Usage of `STO_CFG[2:0]`

2.3. I²C Register Map

| Address | Name | Bit | Field Name | Access | RESET | Description |
|---------|----------|-------|------------|--------|--------------|---|
| 0x00 | VERSION | [3:0] | MINOR | R | - | Chip ID |
| | | [7:4] | MAJOR | R | - | |
| 0x01 | SRCREGU | [6:0] | VALUE | R/W | 0x77 (1.47V) | Source voltage regulation |
| 0x02 | VOVDIS | [5:0] | THRESH | R/W | 0x2D (3.05V) | Overdischarge level of the storage element |
| 0x03 | VOVCH | [5:0] | THRESH | R/W | 0x33 (4.1V) | Overcharge level of the storage element |
| 0x04 | TEMPCOLD | [7:0] | THRESH | R/W | 0x8F (0°C) | Cold temperature level |
| 0x05 | TEMPHOT | [7:0] | THRESH | R/W | 0x2F (45°C) | Hot temperature level |
| 0x06 | PWR | [0:0] | KEEPALEN | R/W | 0x01 | Keepalive enable |
| | | [1:1] | HPEN | R/W | 0x01 | High power mode enable |
| | | [2:2] | TMONEN | R/W | 0x01 | Temperature monitoring enable |
| | | [3:3] | STOCHDIS | R/W | 0x00 | Battery charging disable |
| 0x07 | SLEEP | [0:0] | EN | R/W | 0x01 | Sleep mode enable |
| 0x08 | STOMON | [2:0] | RATE | R/W | 0x00 | ADC rate |
| 0x09 | APM | [0:0] | EN | R/W | 0x00 | APM enable |
| | | [1:1] | RSVD1 | R/W | 0x00 | Write 0x01 when APM is used. |
| | | [3:2] | RSVD2 | R/W | 0x00 | Write 0x00 when APM is used. |
| 0x0A | IRQEN | [0:0] | I2CRDY | R/W | 0x01 | IRQ serial interface ready enable |
| | | [1:1] | VOVDIS | R/W | 0x00 | IRQ STO OVDIS enable |
| | | [2:2] | VOVCH | R/W | 0x00 | IRQ STO OVCH enable |
| | | [3:3] | SLPTHRESH | R/W | 0x00 | IRQ SRC LOW enable |
| | | [4:4] | TEMP | R/W | 0x00 | IRQ temperature enable |
| | | [5:5] | APMDONE | R/W | 0x00 | IRQ APM done enable |
| 0x0B | CTRL | [0:0] | UPDATE | R/W | 0x00 | Load I ² C registers configuration |
| | | [2:2] | SYNCBUSY | R | 0x00 | Synchronization busy flag |
| 0x0C | IRQFLG | [0:0] | I2CRDY | R | 0x00 | IRQ serial interface ready flag |
| | | [1:1] | VOVDIS | R | 0x00 | IRQ STO OVDIS flag |
| | | [2:2] | VOVCH | R | 0x00 | IRQ STO OVCH flag |
| | | [3:3] | SLPTHRESH | R | 0x00 | IRQ SRC LOW flag |
| | | [4:4] | TEMP | R | 0x00 | IRQ temperature flag |
| | | [5:5] | APMDONE | R | 0x00 | IRQ APM done flag |
| 0x0D | STATUS | [1:1] | VOVDIS | R | 0x00 | Status STO OVDIS |
| | | [2:2] | VOVCH | R | 0x00 | Status STO OVCH |
| | | [3:3] | SLPTHRESH | R | 0x00 | Status SRC LOW |
| | | [4:4] | TEMP | R | 0x00 | Status temperature |
| | | [6:6] | CHARGE | R | 0x00 | Status STO Charge |
| 0x0E | APM0 | [7:0] | DATA | R | 0x00 | APM data 0 |
| 0x0F | APM1 | [7:0] | DATA | R | 0x00 | APM data 1 |
| 0x10 | APM2 | [7:0] | DATA | R | 0x00 | APM data 2 |
| 0x11 | TEMP | [7:0] | DATA | R | 0x00 | Temperature data |
| 0x12 | STO | [7:0] | DATA | R | 0x00 | Storage element voltage |
| 0x13 | SRC | [7:0] | DATA | R | 0x00 | SRC ADC value |

Table 4: Register summary

2.4. I²C Communication

The device address on the I²C bus is 0x41. All information about the I²C communication is available in the AEM00900 datasheet, "System configuration" Section.

I²C_VDD must be connected to an external power supply which voltage is within the 1.5 V to 2.2 V range. On the Evaluation Board, 1 kΩ pull-up on SDA and SCL (R1 and R2) to I²C_VDD are provided.

In case one or more configurations are set by I²C communication, none of the configuration pins (GPIOs) will be taken into account anymore. Thus, applying the default values to any registers that have not been explicitly configured by I²C.

2.5. Advanced Configurations

A complete description of the system constraints and configurations is available in Section "System configuration" of the AEM00900 datasheet.

2.5.1. Mode Configuration

DIS_STO_CH

Enabling/disabling battery charging can be done by setting a jumper on the corresponding 3-pin header.

- Use a jumper to connect the DIS_STO_CH to H to disable the charge of the storage element.
- Use a jumper to connect the DIS_STO_CH to L to enable the charge of the storage element.

KEEP_ALIVE

The KEEP_ALIVE feature allows to supply the internal circuitry from the storage element when no power is available on the source terminal.

- Use a jumper to connect the KEEP_ALIVE to H to enable the feature.
- Use a jumper to connect the KEEP_ALIVE to L to disable the feature.

2.5.2. Thermal Monitoring

The thermal monitoring feature protects the battery by disabling the battery charging when ambient temperature is outside a specified range. The higher and lower thresholds are configurable using the I²C communication (see datasheet).

- Place a jumper between TH_MON and VINT to disable the feature.
- Place a jumper between TH_MON and THERM to enable the feature.

3. Functional Tests

This section presents a few simple tests that allow users to understand the functional behavior of the AEM00900. To avoid damaging the board, follow the procedure found in Section 2.1 “Safety Information”. If a test has to be restarted, make sure to properly reset the system to obtain reproducible results.

The measurements use the following equipment:

- Two Source Measurement Units (SMU, four-quadrant power supply).
- One 2-channel oscilloscope.

The following functional tests were made using the following setup:

- EVK jumpers configuration:
 - `SRC_LVL_CFG[5:0]` = LHHHL (0.54 V).
 - `STO_CFG[2:0]` = HHH (3.01 V - 4.12 V).
 - `DIS_STO_CH` = L.
 - `KEEP_ALIVE` = H.
 - Place the jumper to connect `TH_MON` with `VINT`.
- Place a jumper to connect `I2C_VDD` and `GND` if the I²C communication is not used.

Users can adapt the setup to match the use case system as long as the input limitations are respected, as well as the minimum storage voltage and cold-start constraints (see “Introduction” Section of AEM00900 datasheet).

3.1. Start-up

The following example allows users to observe the start-up behavior of the AEM00900.

Setup

- Place oscilloscope probes on `VINT` and `STO`.
- Referring to Figure 1, follow steps 1 to 5 explained in Section 2.1 “Safety Information”.
- `STO`: SMU set as a 3.0 V voltage source with 1 mA current compliance.
- `SRC`: SMU set as a 1 mA or 100 μ A current source with 0.8 V voltage compliance.

Observations and measurements

- `VINT`: voltage rises to 2.2 V.
- `STO`: observe the current absorbed by the SMU as power is transferred from `SRC` to `STO`.

3.2. Shutdown

This test allows users to observe the behavior of the AEM00900 when the system is running out of energy. This test is to be done when the AEM00900 has already started, as at the end of the test described in Section 3.1.

Setup

- Disable the `KEEP_ALIVE` feature (`KEEP_ALIVE` = L).
- Place the oscilloscope probe on `VINT`.
- Referring to Figure 1, follow steps 1 to 5 explained in Section 2.1 “Safety Information”. Configure the board in the desired state and start the system (see Section 3.1).
- Disconnect the SMU from `SRC`.

Observations and measurements

- `VINT`: voltage falls to `GND`.
- `STO`: no leakage from `STO` (probe impedance considered).

3.3. Cold Start

The following test allows users to observe the minimum voltage required to coldstart the AEM00900. To prevent current leakage caused by the probe impedance, users should avoid probing any unnecessary node. Make sure to properly reset the board to observe the cold-start behavior.

Setup

- Place oscilloscope probe on `SRC`.
- Referring Figure 1, follow steps 1 to 5 explained in Section 2.1.
- `SRC`: SMU set as 20 μ A current source with 0.3 V voltage compliance.
- `STO`: SMU as 3.0 V voltage source with 100 μ A current compliance.

Observations and measurements

- `SRC` voltage clamped at the cold-start voltage during the cold-start phase and then regulated at the selected source voltage when cold start is over. The duration of the cold-start phase decreases as the input power increases. Select the input power accordingly to be able to observe the cold-start phase.
- `STO`: SMU starts absorbing current sourced by the `STO` pin once the cold-start phase is completed.

3.4. Thermal Monitoring

The following test allows users to observe the thermal monitoring functionality.

Setup

- Place a 10 kΩ NTC thermistor with $\beta = 3380$ on R_{th} .
- Place a 22 kΩ pull-up resistor on R_{DIV} .
- Place the jumper to connect TH_MON with THERM.
- Place the probes on the nodes to be observed.
- Referring to Figure 1, follow steps 1 to 5 as explained in Section 2.1 “Safety Information”. Configure the board in the desired state and start the system (see Section 3.1).

Observations and measurements

- If the temperature is lower than 0°C, the charge of the storage element is disabled.
- If the temperature is higher than 45°C, the charge of the storage element is disabled.
- If the temperature is between 0°C and 45°C, the charge of the storage element is enabled.

3.5. Keep-alive

The **KEEP_ALIVE** feature sets the behavior of the AEM00900 when no power is available on **SRC**.

Setup

- Place the oscilloscope probe on **VINT**.
- Referring to Figure 1, follow steps 1 to 5 explained in Section 2.1 “Safety Information”. Configure the board in the desired state and start the system (see Section 3.1).
- Enable the **KEEP_ALIVE** feature (connect **KEEP_ALIVE** to H).
- Disconnect the SMU from the **SRC** pin.

Observations and measurements

- **VINT**: the internal circuitry is supplied by the storage element (V_{VINT} does not drop).

3.6. Disable Storage Element Charge

The **DIS_STO_CH** feature allows to disable the storage element charge.

Setup

- Use a jumper to connect **DIS_STO_CH** to H to disable the charge of the storage element.
- **STO**: SMU set as a 3.0 V voltage source with 1 mA current compliance.
- Referring to Figure 1, follow steps 1 to 5 explained in Section 2.1 “Safety Information”. Configure the board in the desired state and start the system (see Section 3.1).

Observations and measurements

- **STO**: observe that no current is absorbed by the SMU on **STO** when power is applied on **SRC**.

3.7. I²C Communication

This test allows users to change a configuration through the I²C communication.

Setup

- Place the oscilloscope probe on **SRC**.
- Referring to Figure 1, follow steps 1 to 5 explained in Section 2.1 “Safety Information”. Configure the board in the desired state and start the system (see Section 3.1).
- Connect **I²C_VDD** to the I²C supply (between 1.8 V and 2.2 V).
- Write ‘0010 0011’ (0x23) on the SRCREGU register (0x01), so that constant source voltage is set to 0.285 V).
- Write ‘1’ to the CTRL register (0x0B) to load the I²C register configuration (at startup the AEM00900 load its configurations from the pins settings).

Observations and measurements

- **SRC**: observe that the voltage regulation switches to 0.285 V, when the register value is loaded.

3.8. Efficiency

This test allows users to reproduce the efficiency graphs of the boost converter (see “DCDC Conversion Efficiency” Section in the AEM00900 datasheet).

Setup

- Referring to Figure 1, follow steps 1 to 5 explained in Section 2.1 “Safety Information”. Configure the board in the desired state and start the system (see Section 3.1).
- **STO**: connect SMU configured as a 4.7 V voltage source with a 100 mA current compliance.
- **SRC**: connect SMU configured as a source current with a voltage compliance of 1.0 V to ensure the AEM00900 coldstarts.

Manipulations

- **STO**: set the SMU to the desired voltage, between V_{OVDIS} and V_{OVCH} . Make sure the SMU integration time is as long as possible.

- **SRC**: sweep the source level voltage by either changing the **SRC_LVL_CFG[5:0]** pins connections (jumpers) or by writing the SRCREGU register by I²C communication.

Observations and measurements

- For each data point of the **SRC** voltage sweep, note the **SRC** SMU voltage and current, as well as the **STO** SMU voltage and current. Repeat the measurement for each data point a copious number of times to ensure capturing current peaks.
- The efficiency η in percent is computed by applying the following formula:

$$\eta = 100 \cdot \frac{V_{STO} \cdot I_{STO}}{V_{SRC} \cdot I_{SRC}}$$

NOTE: to ensure optimal efficiency, make sure a minimal decoupling capacitance of 22 μ F is present on the STO pin.




Figure 2: AEM00900 efficiency (LDCDC: TDK VLS252012HBX-6R8M-1)

4. Schematics




Figure 3: AEM00900 Evaluation Board Schematic

5. Revision History

| EVK Version | User Guide Revision | Date | Description |
|-------------|---------------------|-----------------|--|
| Up to 1.1 | 1.0 | February, 2022 | Creation of the document. |
| 1.2 | 1.0 | September, 2023 | Fixed some inconsistencies and updated images. |
| 1.2 | 1.1 | February, 2024 | Corrected typos and aesthetic modifications. |

Table 5: Revision History